



EQUIPMENT CODE STANDARD “ECS”.

Refrigerated Containers – Component codes, reference guide.

Version May 19, 2025.

IICL workgroup:

SEACO

**Chai Wah Koh
Hendry Xu
Jos Vanstiphout**

**SEACUBE
TEXTAINER**


**Jorge Dias
Alessandro Caldon
Peter Brandon**


TRITON

**Dennis Van Hal
Stijn Doffyn
Toni Jakat**

IICL:

**Luiz Gonçalves
technical@iicl.org**





**Rail Cone
Protector
Recess
RCI**

**T-Floor
Drain
TFD**



**Panel Inner
Cladding
PIC**

**Corner Post
J-bar
CPJ**

**Panel Inner
Cladding
PIC**



**Scuff Plate
/ Lining
PSL**

**T-Floor
Assembly
TFA**

**Load Line
Decal
LLD**

**T-floor Strip
TFI**





**Outer
Gasket
GTO**

**Locking Bar
Cam**



**Rail Cone Protector
Recess
RCI**

**Corner Post
J Bar
CPJ**

**Hinge Pin
HGP**


**Hinge Pin
Lug
CPL**



**Outer
Gasket
GTO**

**Inner
gasket
GIN**

**Hinge Blade
HGB**



**Locking Bar
Handle
LBH**

**Locking bar
bracket
LBB**

**Door Locking
Bar Rod
LBR**



**Door Chain
Hook
DRH**

**Door retainer -
holdback cord /
cable
DRT**

**Outer
Gasket
GTO**

**Inner
Gasket
GIN**



**Rail
Assembly
RLA**

**Panel -
Outer
Cladding
POC**

**Other
Markings
MRU**

**Rail
Assembly
RLA**

**Corner Post
Assembly
CPA**

**High cube
strips
MHC**

**Roof Corner
Gusset
RCG**

**High cube
strips
MHC**



**Serial Number
and Check Digit
MSN**

**Header
Extension Plate
HEP**

**Corner
Fitting
CFG**

**Rail
Assembly
RLA**

MAX GROSS 35,000 KG
TARE 4,650 KG
PAYLOAD 30,350 KG
CU. CAP. 67.6 CUM



Corner Post
Assembly
CPA

Rail
Assembly
RLA

Rail
Assembly
RLA


Corner Post
Assembly
CPA




Rail
Assembly
RLA

Rail
Assembly
RLA

Rail
Assembly
RLA





Corner
Fitting
CFG

High cube
strips
MHC

Clip-on
Genset
Clamp Socket
COS

Hardware
HWR

Evaporator
Access
Panel
VAP



Evaporator
Access Panel
VAP


Air Exchange
Vent
ARE

Electrical
Box
BEA

Compressor
- Complete
with Motor
ASY

Rail
Assembly
RLA

Cable Guard
Small
QPS



Bulkhead
plate/panel
center
PBK

Rail
assembly
RLA

Panel inner
cladding
PIC

Scuff
plate/lining
PSL

T-floor strip
TFI

Rail cone
protector
recess
RCI

Rail
assembly
RLA



Interior
coving
TCI

Load line de
Load line
decal
LLD

Bulkhead
plate/panel
center
PBK

T-floor
assembly
TFA

Evaporator
grille
GLI

Side
Bulkhead
doors
EPA

Bulkhead
plate/panel
center
PBK

T-floor
baffle plate
TFF


T-floor baffle
plate hinge
holder
THH

T-floor
baffle plate
hinge
TFH



Front Baffle
Plate
Supports
BPS

Baffle
Support
Channels
BSC



**SPRING
KSS**

**Side
Bulkhead
door
EPA**


**Bulkhead
inner panel
INP**



**T-floor
assembly
TFA**

**T-floor
casting
TFC**

**T-floor end
seal
TFS**




**T-floor strip
TFI**

**Rail
assembly
RLA**

**Cam keeper
RCK**



Panel edge
profile
PEP





Self -opening
Drain
DKK


Subfloor
PAA

Cross-
member
assembly
CMA


Tunnel
Bolster
TUB

Gooseneck
Tunnel Rail
RTL





NOTE: Considering the large number of machinery components, diversity of manufacturers and models, this document will focus on the more common components among all machine manufacturers for your immediate assistance. The IICL strongly suggests that you refer to the manufacturers' manuals for proper guidance on component names, component locations, and part serial numbers.







Condenser grille
GLK

Air exchange vent
ARE

Cable 460 V
ECB


Power cable box /
guard
QPS

Compressor complete
ASY

Evaporator access panel
VAP


Clip-on genset clamp socket
COS

Controller keypad
CKP




Custom seal
point
FCP

Custom seal
point
FCP








Hardware
HWR

**Probe Cover
Refer to
Manuf.
Manual**


**DSV
connector cap
VCC**

**Valve stem
cap
KVC**



**Suction
Modulating
Valve
VMA**





Contactors
Refer to
Manuf.
manual

Wiring
WIR

Wiring
WIR

Contactors
Refer to
Manuf.
manual


Circuit
breaker 460 V
CBR

Display
assembly
BDA

Mother
electronic
board
BMN

Controller
keypad
CKP





Contactors
Refer to
Manuf.
manual

Contactors
Refer to
Manuf.
manual

Circuit
breaker, 460 V
CBR


Circuit breaker
bracket/mount
CBM

Current
Transformer
CTF

**Coil assembly
condenser
CSK**

**Motor -
condenser fan
motor
MKS**

**Drain tube
DRN**




**Fan-
condenser
motor
FKN**

**Condenser
grille
GLK**

**Condenser
door panel
CDP**




**Condenser
door hinge
CRH**



**Electrical
diagram
EDX**


**Electrical
diagram
holder
EDH**




**Evaporator
grill
EGT**

**Coil fins –
evaporator
CFV**

**Drain pan
DPA**






Evaporator
coil heaters
HVC

Drain pan
DPA

Coil assembly
– evaporator
CSV

Evap. motor
mount
EMM




**Coil assembly
– evaporator
CSV**

**Evaporator
motor – elecc.
Connections
MVE**


**Motor -
evaporator
fan motor
MVS**

**Evap. fan
housing
(right and
left housing)
VFH**

**Evap. motor
mount
EMM**



Evaporation coil defrost
temperature sensor
EVS



Piping, other
PMI


Support
bracket, pipe
system
TSB

Evaporator
coil heaters
HVC

Evap. fan
motor –
bracket
VFC




**Drain pan
DPA**



Coil fins –
evaporator
CFV


Evaporator
coil heaters
HVC

Heater
holding back
strip
HHS




Wiring
WIR

Piping
PMI



**Hardware
huck bolts
HWH**




**Hardware
HWR**

**Locking bar
bracket
LBB**

**Locking bar
cam
LBC**

**Cam keeper
RCK**

**Self-
opening
drain
DKK**





**Markings
MRK**

**Electrical
diagram
EDX**

**Controller
box door
BCD**